

Boxenstativ 214/6

SPEAKER STAND 214/6

zusammenlegbar, höhenverstellbar
FOLDING, HEIGHT ADJUSTABLE

Bedienungsanleitung

Zur Aufstellung FüÙe auseinanderziehen - Querstreben in **waagrechte** Lage bringen - und mit Klemmschraube **3** fixieren.

Zur Höhenverstellung Klemmschraube **2** lösen, Rastbolzen **1** herausziehen und in entsprechender Lochung wieder einrasten lassen, Klemmschraube **2** festziehen.

ACHTUNG: Auszugsrohr nur im gesicherten Zustand belasten! Stativ nicht einseitig belasten !

Das Zusammenlegen erfolgt in umgekehrter Reihenfolge.


INSTRUCTIONS

FOR SET-UP, SPREAD LEGS APART TO DESIRED BASE WIDTH. FOR MAXIMUM STABILITY IT IS RECOMMENDED BRINGING THE BRACES TO THE **HORIZONTAL** POSITION. TIGHTEN LOCKING KNOB **3**.

FOR HEIGHT ADJUSTMENT, LOOSEN LOCKING SCREW **2**, PULL OUT STOP BOLT **1** AND INSERT AGAIN IN DESIRED HEIGHT PERFORATION, TIGHTEN LOCKING SCREW **2**.

WARNING: LOAD EXTENSION TUBE IN SECURED STATE ONLY! DO NOT PLACE UNBALANCED LOAD ON STAND!

FOLD STAND IN REVERSE WAY.



Bitte beachten: die angegebenen Positions-Nummern entsprechen nicht den Ersatzteil-Bestell-Nummern!

PLEASE NOTE: ABOVE NUMBERS ARE NOT OUR ORDINARY SPARE PART NUMBERS!



MAX. ZENTR. BELASTUNG: 500 N (50 kg)
 MAX. CENTRIC LOAD: 500 N (50 kg)